

Alternate Hearing Devices Category

BERNAFON

Service Code	Service Code Description
ABBW0082	HEARING AID - BERNAFON Juna 9 Compact Power Plus BTE
ABBW0083	HEARING AID - BERNAFON Juna 9 Power BTE
ABBW0084	HEARING AID - BERNAFON Juna 9 Compact Power BTE
ABBW0085	HEARING AID - BERNAFON Juna 9 Nano BTE
ACBW0046	HEARING AID - BERNAFON Juna 9 ITC Directional
ACBW0047	HEARING AID - BERNAFON Juna 9 ITC Power Directional
ACBW0048	HEARING AID - BERNAFON Juna 9 ITC
AIBW0013	HEARING AID - BERNAFON Juna 9 ITE Directional
AIBW0014	HEARING AID - BERNAFON Juna 9 ITE Power Directional
ANBW0030	HEARING AID - BERNAFON Juna 9 CIC Power
ANBW0031	HEARING AID - BERNAFON Juna 9 CICx
ANBW0032	HEARING AID - BERNAFON Juna 9 CIC
ARBW0005	HEARING AID - BERNAFON Juna 9 Nano RITE
ARBW0006	HEARING AID - BERNAFON Juna 9 Pico RITE

PHONAK

Service Code	Service Code Description
ABPY0065	HEARING AID - PHONAK NAIDA V90-RIC RITE
ABPY0080	HEARING AID - PHONAK Naida V90-SP BTE
ABPY0081	HEARING AID - PHONAK Naida V90-UP BTE
ABPY0082	HEARING AID - PHONAK Bolero V90-M BTE
ABPY0083	HEARING AID - PHONAK Bolero V90-P BTE
ABPY0084	HEARING AID - PHONAK Bolero V90-SP BTE
ACPY0040	HEARING AID - PHONAK VIRTO V90-10 NW O MC
ACPY0041	HEARING AID - PHONAK VIRTO V90-10 NW O ITC
ACPY0042	HEARING AID - PHONAK VIRTO V90-10 O MC
ACPY0043	HEARING AID - PHONAK VIRTO V90-10 O ITC
ACPY0044	HEARING AID - PHONAK VIRTO V90-10 MC
ACPY0062	HEARING AID - PHONAK Virto V90-10 ITC
ACPY0063	HEARING AID - PHONAK Virto V90-312 ITC
ACPY0064	HEARING AID - PHONAK Virto V90-13 ITC
AIPY0061	HEARING AID - PHONAK VIRTO V90-10 NW O HS
AIPY0062	HEARING AID - PHONAK VIRTO V90-10 NW O FS
AIPY0063	HEARING AID - PHONAK VIRTO V90-10 O HS
AIPY0064	HEARING AID - PHONAK VIRTO V90-10 O FS
AIPY0065	HEARING AID - PHONAK VIRTO V90-10 HS
AIPY0066	HEARING AID - PHONAK VIRTO V90-312 HS
AIPY0067	HEARING AID - PHONAK VIRTO V90-13 HS
AIPY0089	HEARING AID - PHONAK Virto V90-10 ITE
AIPY0090	HEARING AID - PHONAK Virto V90-312 ITE
AIPY0091	HEARING AID - PHONAK Virto V90-13 ITE
ANPY0012	HEARING AID - PHONAK VIRTO V90-NANO IIC

ANPY0013	HEARING AID - PHONAK VIRTO V90-10 NW O CIC
ANPY0014	HEARING AID - PHONAK VIRTO V90-10 O CIC
ARPY0019	HEARING AID - PHONAK Audeo V90-10 RITE
ARPY0020	HEARING AID - PHONAK Audeo V90-312 RITE
ARPY0021	HEARING AID - PHONAK Audeo V90-312T RITE
ARPY0022	HEARING AID - PHONAK Audeo V90-13 RITE
ARPY0024	HEARING AID - PHONAK Audeo B90-10 RITE
ARPY0025	HEARING AID - PHONAK Audeo B90-13 RITE
ARPY0026	HEARING AID - PHONAK Audeo B90-312 RITE
ARPY0027	HEARING AID - PHONAK Audeo B90-312T RITE

SIVANTOS

Service Code	Service Code Description
AISM0047	HEARING AID - SIEMENS (REXTON) TRAX 42 HS
ABSM0091	HEARING AID - SIEMENS (REXTON) TRAX 42 XM (RIC) RITE
ABSM0083	HEARING AID - SIEMENS REXTON TRAX 42 (RIC)
ARSM0014	HEARING AID - SIVANTOS Rexton Emerald M 80 4c/Trax 42 XM RITE
ARSM0013	HEARING AID - SIVANTOS Rexton Emerald S 80 6c/KS7 RITE
ARSM0012	HEARING AID - SIVANTOS Rexton Emerald XS 80 4c/Trax 42 XS RITE
ABSM0111	HEARING AID - SIVANTOS Rexton Mosaic M 80 4c/Trax 42 MB BTE
ABSM0112	HEARING AID - SIVANTOS Rexton Mosaic P 80 4c/Trax 42 PB BTE
ACSM0031	HEARING AID - SIVANTOS Rexton Trax 42 ITC
AISM0057	HEARING AID - SIVANTOS Rexton Trax 42 ITE
ARSM0010	HEARING AID - SIVANTOS Siemens Carat 7bx RITE
ARSM0011	HEARING AID - SIVANTOS Siemens Carat A 7bx RITE
ABSM0110	HEARING AID - SIVANTOS Siemens Motion P 7px BTE
ARSM0008	HEARING AID - SIVANTOS Siemens/Signia Ace 7px RITE
ANSM0031	HEARING AID - SIVANTOS Siemens/Signia Insio 7px CIC
ACSM0030	HEARING AID - SIVANTOS Siemens/Signia Insio 7px ITC
AISM0056	HEARING AID - SIVANTOS Siemens/Signia Insio 7px ITE
ABSM0109	HEARING AID - SIVANTOS Siemens/Signia Motion SA 7px BTE
ABSM0108	HEARING AID - SIVANTOS Siemens/Signia Motion SX 7px BTE
ARSM0009	HEARING AID - SIVANTOS Siemens/Signia Pure 7px RITE